Instructions for Connecting Microphones

Two microphones may be used simultaneously

Connecting the Podium Microphone

- 1. Use a microphone cord either located in the open space under the podium or in the equipment cabinet.
- 2. Connect one end of the cord to the jack in the bottom right corner of the podium and the other into either of the jack on the wall. Mic 1 or Mic 2.

Connecting the Wireless Lavaliere

- 1. Plug the power cord into the A/C jack on the back of the Amplifier; then plug into the electrical outlet on the wall.
- 2. Plug the microphone cord into the mic jack on the back of the Amplifier; then plug the other end into one of the mic jacks on the wall.
- 3. Turn it on (on the front).
- 4. Turn on the Lavaliere by pressing and holding the single top button on the front. The code will match the code to the Amplifier.
- 5. There is a volume control on the back of the Amplifier.
- 6. There is a volume control on the wall by the light switch a silver plate with a black knob.
- 7. To replace the batteries, unlock the side slide bar; squeeze the two arrows together; the door will open; replace batteries; shut the door; slide the lock into place.

Extra batteries are kept in the tray with the Wireless Lavaliere. If you use the last battery, please notify the GHF Office.

<u>Connecting the Wireless Handheld</u> (original box) [Table top stand or floor stand available.]

- 1. Follow the same steps as the Lavaliere turn on the handheld by pressing and holding the button on the bottom of the microphone.
- 2. To mute, press it once. Unmute, press once.
- 3. To turn off, press and hold.
- 4. To change the batteries, unscrew the top and pull out; change out batteries; line up and push bottom back onto the top; tighten.

<u>Connecting the Handheld Microphone (corded)</u> [Table top stand or floor stand available.]

- 1. Use a microphone cord located in the equipment cabinet (Miscellaneous Tray).
- 2. Connect one end of the cord to the jack in the bottom of the microphone and plug the other end into either of the jacks on the wall. Mic 1 or Mic 2.